

Fabric-Form® Application Instructions

Stahl's Hotronix Press



This Fabric-Form instruction sheet was developed using a Hotronix press with a **Bottom Heat Platen**. Since every heat press is different, we recommend testing the heat/time on your specific press. We also offer instructions using GeoKnight presses at www.fabric-form.com.



Press settings:


Top Platen Heat: as low as possible (175°)

Bottom Platen Heat: 325° - 350°

Pressure: 9

1.

2. Remove the liner from the back of the emblem.



Position the emblem on the shirt in the desired location.

3.

Optional: you can add a thin strip of Stahl's Thermo Tape on top of the emblem to hold it in place.